

Sumax Sportster® Saddle Bag & Bracket Installation

(Fig 1.1)



Remove OEM Shock Bolt, this bolt will be replaced with new bracket mounting shock bolt supplied by Sumax.

(Fig 1.2)



Install new bracket mounting shock bolt supplied with your kit.

(Fig 1.3)



Remove rear OEM turn signal. Please retain mounting stem bolt as this will be used for a bracket mount.

(Fig 2.1)



Align bracket with mounting studs on supplied shock bolt and OEM turn signal stud.

(Fig 2.2)



Install mounting nuts using Blue Loctite® or equivalent thread locker.

(Fig 2.3)



Install supplied DZUS receptacles to brackets. Do not tighten bolts in this step, leave loose for adjustment in figure 3.2.

(Fig 3.1)



Install supplied rubber bumpers to bracket bottom support bar.

(Fig 3.2)



Install bags using supplied 1/4 turn fasteners. You will have to adjust / rotate DZUS receptacles to align mounting holes.

(Fig 3.3)



When 1/4 turn fasteners are installed and bag is resting securely on bottom support bracket, tighten DZUS receptacle.

Sumax Cycle Products

122 Clear Rd • Oriskany, NY • Ph. 315-768-1058 • Fx. 315-768-1058

www.sumax.com